								Work Streams			_					
PM		Team 1	Team 2	Team 3	Team 4	Team 5	Team 6	Team 7	Team 8	Team 9	Team 10	Team 11	Team 12	Team 13	Team 14	
		Projection Team	Cleansing Team	Security and Crowd Control at QVS	Cranos	Supports	Ballast	Police Escort	Plade	Signals (2 gangs of 2 nnl)		Hull City Center Lighting &	Traffic Management	Droce	Volunteer Parade	
Org			Cleansing Team Hull CC 2017	Hull CC 2017		Supports DB Engineering		Hull Police		Signals (2 gangs of 3 ppl) North Midlands		signals (2 gangs of 3ppl) North Midlands			Hull CC 2017	
Name Time Mobi		Chris Clay 7771 788221	Chris Clay 7771 788221	Chris Clay 7771 788221		Darren B 07790 666002		PC Darren Storr 07919 690101		Jon Hudson 7968 766603	Jon Hudson 7968 766603	Jon Hudson 7968 766603			Ben McKnight 07718 100793	
	one.	7771 760221	7771700221	7771700221	7331 312330	Tip supports loaded the nig		07913 030101	Blade loaded onto transport	7500 700003	7300 700003	7308 700003	7500 700003	07718 100733	07718 100793	
20:30 20:40						before			system							
20:50																
	ifinished; Cleanse Square; Mark out tripod		Quiclk cleanse of	Start stewarding the public												
21:00 locati 21:10	tions	Event Finishes	square	out of QVS												
21:20																
21:30 Put u	up barriers for crowd control;			Start putting up crowd contro barriers around QVS												
21:40	ap same store crown control,			Samers around QVS												
21:50																
QVS i 22:00 Place	is clear; South Bound road closure on Market		Leave QVS										Southbound Road closure on Market Place			
22:10	е		Leave QV3										iviarket Place			
22:20 22:30																
22:40																
22:50												Turn 2: Lighting and signs				
23:00												removed				
23:10 23:20																
						Two birehead that										
23:30 Kick o	off for Named team leads					Two hi-abs with tip suppor and root sets off to QVS	TT									
23:40 23:50																
										Turns 6 & 7: Switch from						
	oort delivery to square and start offloading; as 6 & 7 on temporary signals	Partial possession for Blade teams				Arrive at QVS and offload sections				permanent to temporary signals			TM on Turns 5, 6 & 7			
00:10	and an emperously engineer															
00:20																
00:30 Start	t asembling supports					Start Assembling tip suppo with transport hi-ab	ort									
	t datinishing adoptorts					with transport in as										
00:40 00:50																
							Crane company starts delivering ballast to QVS and									
	a 2 ready; Blade sets off from Alexander Docks;						stockpiles them adjacent to	Set off from Alexander Docks				Turrn 7: Lighting and signs				
01:00 1st lo 01:10	oad of ballast delivered						tip support	to QVS- leap frogging	Alexander Docks			removed				
01:20																
01:30 01:40																
01:50	rly catch up with all leads								Exit turn 2	Turn 4: signals removed	Turn 4: Lighting removed					
02:10	ny caten up with an leaus						2nd load delivered to site		LXIC CUTT 2	Turri 4. signais removed	Turn 4. Lighting removed					
02:20						Drill and resin fix bolts for t	tip							Press Mount Pleasant (under		
02:30 02:40						support			Exit turn 3					flyover)		
02:40																
Hour	rly catch up with all leads; Turn 4 & 7 ready;											Turn 2: Lighting and signs		Press on terrace at Premier Inn		
03:00 Reins									Exit turn 4	Turn 5: signals removed	Turn 5: lighting removed	reinstated		hotel		
03:10 03:20							3rd Load delivered to site									
03:30 Turn :	n 5 ready								Start Turn 5		Reinstate turn 4 lighting					
03:50								Diode off ACC	Died - off A CO O					Dragger and Community of the Community o		
04:00 Hour	rly catch up with all leads; Blade leaves A63			QVS - full posession				Blade off A63- vigilant of public	Blade off A63 & arrives at Market Place		Start reinstating A63			Press on Queen Street /A63 corner		
04:10 04:20							4th load delivered to site									
							tip Start loading on ballast for tip									
04:30 Blade 04:40	le leaves Market Place				Set off to QVS	support	support		Blade leaves Market Place							
04:50		Logue OVC														
		Leave QVS- potential for small work area														
	rly catch up with all leads; QVS - full posession & le leaves A63	near Maritime museum			Arrive at QVS and start setting				From Turn 6 to Exit of Turn			Turn 7: Lighting and signs reinstated		Press bus folllows convoy from Turn 6		
05:10	C 1541C5 1105	Museum			MP.		4th load delivered to site				Tarrior ngriting remotated	. enistated		.uiii 3		
05:20 05:30						Apply grout under feet										
05:40 Hand	d A63 to Highways England for inspection															
05:50										Turn 6 & 7: Switch from						
	rly catch up with all leads; A63 is reopened to lic; Cranes arrive at A63				Root crane set up at QVS					temporary to permanent				Siemens crowd and press at Carr Ln/Cross St		
										<u>signals</u>					Staff (max 200) outside	
06:10 Tip su	support is secure		1			Tip support ready								<u> </u>	Maritime Museum	

						•				1			
РМ	Team 1 Team 2	Team 3	Team 4	Team 5	Team 6	Team 7	Team 8	Team 9	Team 10	Team 11	Team 12	Team 13	Team 14
		Close off roads to ensure that no pedestrians pass on Carr											
06:30 Carr lane closed for pedestrians		lane and under any lifting operations											
06:40		operations											
06:50													
Hourly catch up with all leads; Blade arrives at 07:00 Saville Street		Be vigilant of anyone attempting to enter square				Exit of Turn 7	Exit of Turn 7				FinishTM on Turns 5, 6 & 7	Press at City Hall	
07:10 07:20													
						Blade manouvered onto QVS-							
07:30 Blade manouvered into QVS 07:40			Set up root crane			ready for lifting	QVS- ready for lifting						
07:50													
Hourly catch up with all leads; Tip crane set up; 08:00 blade lifted off transportes			Lift blade off of the transporters	Lift blade off of the transporters									
08:10			the state of the s	. anoportore									
				Blade resting on ground to			Blade resting on ground to						
08:20			remove feet and attach feet	remove feet and attach feet			remove feet and attach feet						
08:30 08:40													
08:50 Blade on ground and tranport feet removed			Turn and lift up blade in the	Turn and lift up blade in the			Turn and lift up blade in the						
	All areas on QVS clear		correct orientation	correct orientation			correct orientation	Finished					
09:10 09:20													
09:30 09:40													
09:50 10:00													
10:10													
10:20 10:30													
10:40 10:50													
11:00 Catch up with all leads; Blade in air with correct feet and root support				Root support manouvered									
11:10 manouvered into place				into place									
11:20				Load 9 tonne ballast onto									
11:30 11:40				root support									
11:50 12:00				Bolt plate on top of root									
12:10			Drop blade onto support and	Drop blade onto support and			Drop blade onto support						
			bolt feet onto top of root	bolt feet onto top of root			and bolt feet onto top of						
12:20 Blade dropped onto suppoirts			support	support			root support						
12:30 12:40													
12:50 Check blade is secure and in correct positon				Ensure support is in right position			Ensure support is in right position						
				Start drilling and resin fixing			Start drilling and resin fixing						
13:00 Catch up with all leads;				the bolts for the support			the bolts for the support						
13:10 13:20 13:30													
13:30 13:40													
13:50 Start packing away crowd control measures Catch up with all leads;root support drilled and				Root support secured in									
14:00 resin fixed into ground.				palce. Pour grout under feet									
			Check blade is secure and in	Check blade is secure and in			Check blade is secure and in					1	
14:20 14:30 Blade released by cranes			correct positon Release blade	correct positon Release blade			correct positon						
14:40		Start packing away crowd											
14:50 15:00		control measures	Crane start derigging										
15:10													
15:20 Cranes leave QVS 15:30 Hand QVS over to Hull City Council			Cranes leave QVS										
15:40 15:50													
16:00													